

Marbleized



Tobey Renee Sanders | Limited Edition | Fall 2019

PRODUCTS NEEDED

- Benjamin Moore OC-65 Chantilly Lace
- Golden Paintworks Venetian Plaster
- Golden Paintworks Pre-Mixed Metallic Paint in White Veil, White Gold, and Bright Silver
- 3M Stencil Adhesive Spray
- Wallovers Marbleized Stencil

TOOLS NEEDED

- Paint Roller
- Steel Plaster Trowel
- Plastic Trowel
- Stencil Brushes



HOW TO:

- 1 | **PAINT** basecoat color, OC-65 Chantilly Lace by Benjamin Moore. Let dry.
- 2 | **TROWEL** on 2 skim coat layers of untinted Venetian Plaster. Let dry. *(Photo 1)*
- 3 | **BURNISH** Venetian Plaster with plastic trowel to a beautiful sheen. *(Photo 2)*
- 4 | **PREP** Marbleized stencil. Spray back of the stencil with stencil adhesive spray. Let dry 20 minutes.
- 5 | **PLACE** stencil over burnished Venetian Plaster surface. Stipple over stencil with White Veil, White Gold, and Bright Silver Metallic paint. Blend all 3 colors across the stencil at the same time. Pull stencil carefully and let dry. *(Photo 3)*