

Mica



Tobey Renee Sanders | Limited Edition | Fall 2019

PRODUCTS NEEDED

- Benjamin Moore OC-65 Chantilly Lace
- Golden Paintworks Sandstone
- GlamRock by The Faux Pro in colors Champagne, Gold, and Pewter

TOOLS NEEDED

- Paint Roller
- Steel Plaster Trowel
- Blender
- Mixing Containers and Stirrers
- Drill and Mixing Bit
- 320 Grit Sandpaper

HOW TO:

- 1 | **PAINT** basecoat color, OC-65 Chantilly Lace by Benjamin Moore. Let dry. *(Photo 1)*
- 2 | **TROWEL** on a smooth layer of Sandstone. Let completely dry. *(Photo 2)*
- 3 | **BLEND** up Champagne, Gold, and Pewter GlamRock in a blender until completely diced. Add diced up GlamRock to Sandstone in a separate container and add 30% water to this mix. Blend carefully and blend well with a drill and mixing bit. *(Photo 3)*
- 4 | **TROWEL** on a thin layer of the GlamRock/Sandstone mix over the dry Sandstone. Let dry completely. *(Photo 4)*
- 5 | **SAND** with 320 sandpaper to lightly knock down loose GlamRock in the Sandstone and expose the GlamRock that is embedded in the plaster. *(Photo 5)*

